



We recommend the drill point to be located 15mm from the bottom edge of the substrate