

### Chain Mesh Sign Bracket (supplied with a M8 x 1.25p x 25mm bolt)

These nylon brackets are designed to work with multiple sizes of chain link fences and will not rust. They are attached behind the sign thereby sandwiching the fence between the bracket and the sign.

The Chain Mesh Sign Bracket should be installed around the perimeters of a sign. Install the brackets at the corners of the sign, and install additional brackets every 60 to 90cm around the perimeter as illustrated below.

