


ATTENTION



Do NOT insert the end of the pole with the bolt through the top of the base.



Instead, insert the pole from the bottom end of the base using the end that **does not have a bolt**.

The bolt on the end of the pole is designed to prevent the pole from being pulled out of the base while the base is being moved around.

The pole should not offer any resistance when inserted into the base.

Too much force may cause permanent damage to the base and/or cause water leaks. If you feel any resistance while inserting the pole, stop immediately and revisit the instructions above, or contact us.



Pole end with bolt



Pole end without bolt